

ORDER INVOICE WITH ENGINEERING BREAKDOWN [3FZ02080]

OCTOBER 16, 2017

(3FZ02080)-ENGINE (4RJ00584)-GENERATOR (9EP00557)
-GENSET

For Help Desk Phone Numbers [Click here](#)



Caution Ordering Parts from TMI Order Invoice with Engineering Breakdown

Order Invoice with Engineering Breakdown information is provided by the orders system, once you click breakdown of a part, TMI pulls the information from the Engineering Data System (EDS).

EDS is not a manufacturing bill of material system but a engineering part in effect system. TMI uses the built date and calls EDS to pull the part in effect at that time.

Recently, TMI added an as manufactured tab. This tab provides the consist as reported from the engine factory. This data is limited but growing for new manufactured engines. To see an example enter "WRH00104"

To validate you are ordering a correct part, TMI encourages you to contact Morton Parts. 800-566-7782 or tech_support@cat.com

The below option will email full breakdown of the serial number

☒ Excel ☐ PDF

[FullBreakDown](#)

Sales Model: 3412
DIT

Invoice Number: GE
281023

Dealer:
B293

S.O. Number:
JWJ1400

Invoice Date: 2001-01-
24

[Feature Code](#)

[Part Numbers](#)


[Help](#)

Feature Codes [Top](#)

28 results found, displaying 1 to 28



Reference Number	Eng Chg	Quantity	ASM	LESS	Set Type	Reference Drawing	Description
KW00500	F	1	I				500 EKW W/FAN
412DE1J	F	1	I				3412 480/277V 60 HZ
ENCWP14	F	1	I				WEATHER PROT ENCL-IND - YELLOW
FTBDW34	F	1	I				SDW FUEL TNK BS-1000GAL(3785L)
FUMDIS1	F	1	I			Drawing...	FUMES DISPOSAL
EXTEN01	F	1	I			Drawing...	EXTENSION
EXTEN04	F	1	I			Drawing...	EXTENSION
EMCENGU	F	1	I				ENGLISH DISPLAY UNITS
EMCCPRH	F	1	I			Drawing...	CONTROL PANEL MOUNTING - RH
EMCCAS1	F	1	I				COMMON ALARM/SHUTDOWN
EMCAM06	F	1	I				ALARM MODULE - NFPA 99
COLHTR2	F	1	I				JACKETWATER COOLANT HEATER
AFTS101	F	1	I				AUTO FUEL TRANS SYS1 (AFTS1)
BTC1014	F	1	I				BATTERY CHARGER-10AMP DUALRATE
BAT2416	F	1	I			Drawing...	OVERSIZE BATTERY
CNTCT01	F	1	I				CONTACTOR GP

28 results found, displaying 1 to 28

Reference Number	Eng Chg	Quantity	ASM	LESS 	Set Type	Reference Drawing	Description
CBK0048	F	1	I			Drawing...	800AMP 3-POLE CIRCUIT BREAKER
PTSREM1	F	1	I				REMOVAL AR-POWER TERM. STRIP
CBRH002	F	1	I			Drawing...	CIRCUIT BREAKER - RH
CBS3P02	F	1	I				AUXILIARY SWITCH
60H0480	F	1	I				60HZ 480 VOLTS
MSEPGGN	F	1	I				GENERAL EPG
STANDBY	F	1	I				STANDBY POWER APPLICATION
LANENGO	F	1	I				ENGLISH LANGUAGE OPTION
NONCERT	F	1	I				NON-CERTIFIED
2301GOV	F	1	I				2301 GOVERNOR
EMCPTWO	F	1	I			Drawing...	ELECTRONIC MODULAR CONTROL PNL
BOTCBLE	F	1	I			Drawing...	BOTTOM CABLE ENTRY CIRCUIT BKR

Part Numbers [Top](#)

87 results found, displaying 1 to 87

Reference Number	Eng Chg	Quantity	ASM	LESS 	Set Type	Description	Reference Drawing	SIS Part Diagram 
PP4127	02	1	I			749 BHP 515 GEN KW WOF 60 HZ S		View Diagram
0P9185		1	I			0P9185 PWR PRICING PGM769-00		View Diagram
0V1317		1	I			01JAN01 PRC PROTECT PGM641-11		View Diagram
CA1277	05	1	I			ENGINE AR-BASIC 3412 DIT PKG G		View Diagram
1676899	00	1	I			GENERAL AR-3412 DIT GEN SET		View Diagram
1668592	02	1	I			ENGINE AR - BASIC		View Diagram
3L0284		1	I			TEST - PKG GEN SET	Drawing...	View Diagram
3L0303		1	I			ADJUSTING-WW 2301 CONTROL SYS		View Diagram
3N8594	03	1	I			COVER GP-ENG/GEN LIFT EYE		View Diagram
5P2506	00	1	I			LITERATURE - ENGLISH	Drawing...	View Diagram
6N8878	02	1	I			FUEL PRESSURE GAUGE		View Diagram
1195148	01	1	I			COOLANT-LONG LIFE-BULK-1 LITER		View Diagram
1426947	04	1	I			SENSOR GP-LEVEL-LOW COOLANT		View Diagram
1439518	05	1	I			REGULATOR GP - VOLTAGE		View Diagram
1497876	03	1	I			FASTNER GP-COUPPLING-GENERATOR		View Diagram
1497899	02	1	I			SENSOR GP - ENGINE		View Diagram
1517733	04	1	I			SWITCH GP - DISCONNECT		View Diagram
1533434	03	1	I			MOUNTING GP-ENGINE-FLEXIBLE		View Diagram
1556256	00	1	I			CONTROL GP-GOVERNOR SPEED		View Diagram
1558892	03	1	I			DROOP KIT (VR3)		View Diagram
3L0432		1	I			TEST - PKG GEN SET (EMCP II)		View Diagram
1683241	05	1	I			ENCLOSURE GROUP		View Diagram
1683290	02	1	I			CLEANER GP-AIR-SINGLE ELEMENT		View Diagram
1690198	07	1	I			PANEL GP - EMCP II		View Diagram
1690226	03	1	I			BOX GP - JUNCTION		View Diagram

1690247	05	1	I	BOX GROUP-BREAKER	View Diagram
1690296	02	1	I	CONNECTION GP - GENERATOR	View Diagram
1692050	08	1	I	RADIATOR GP	View Diagram
1694439	03	1	I	HARNESS ASSEMBLY-WIRING SENSOR	View Diagram
1694441	03	1	I	HARNESS ASSEMBLY-WIREING BASIC	View Diagram
1694444	03	1	I	HARNESS AS - WIRING - GOV	View Diagram
1694450	02	1	I	HARNESS ASSEMBLY-WIRING AC	View Diagram
1737080	00	1	I	GENERATOR AR-SR4B 591 FRAME PM	View Diagram
1803986	02	1	I	MTG GP - JUNCTION	View Diagram
1560040	00	1	I	TRANSFORMER GP	View Diagram
1888214	01	1	I	GUARD GP - BELT	View Diagram
CA1907	02	1	I	ENCLOSURE GP-GENERATOR	Drawing... View Diagram
1881003	02	1	I	ENCLOSURE GP - GENERATOR	View Diagram
CA1891	02	1	I	BASE GP-FUEL TANK	View Diagram
1683252	02	1	I	LINES GROUP - DRAIN-COOLANT	View Diagram
1692121	01	1	I	LINES GROUP - DRAIN OIL	View Diagram
1708402	02	1	I	BASE GP - ENGINE & GENERATOR	View Diagram
1708426	01	1	I	LINES GROUP - FUEL	View Diagram
1714503	02	1	I	BASE GP - FUEL TANK - 1000 GAL	View Diagram
1988793	00	1	I	SUPPORT GP - BATTERY	View Diagram
CA1942	00	1	I	REMOVAL AR-DISPOSAL GP	View Diagram
1692120	01	1	I	DISPOSAL GROUP - FUMES	View Diagram
1883851	03	1	I	EXTENSION GP	View Diagram
1883854	01	1	I	EXTENSION GP	View Diagram
CA0846	02	1	I	ENGLISH DISPLAY UNITS	View Diagram
1214713	00	1	I	ENGLISH DISPLAY UNITS	View Diagram
CA1787	01	1	I	MOUNTING GP-CONT PANEL (RH)	View Diagram
1692106	02	1	I	MOUNTING GP. - CONTROL PANEL	View Diagram
CA1430	02	1	I	RELAY GP-COMMON ALARM/SHUTDOWN	View Diagram
1716833	02	1	I	RELAY GP	View Diagram
1902565	01	1	I	HARNESS AS	View Diagram
CA1436	01	1	I	CONTROL GP-ALARM MODULE-NFPA99	View Diagram
1716827	03	1	I	CONTROL GP	View Diagram
CA1389	01	1	I	HEATER GP-JACKET WATER-6000 WA	Drawing... View Diagram
1683238	02	1	I	HEATER GROUP - JACKET WATER	View Diagram
1716841	02	1	I	CONNECTION GP	View Diagram
CA1478	01	1	I	FUEL GP-AUTOMATIC TRANSFER SYS	Drawing... View Diagram
1714492	00	1	I	PUMP GP - FUEL TRANSFER	View Diagram
1716835	02	1	I	CONNECTION GP - ELECTRICAL	View Diagram
CA1946	01	1	I		View Diagram

				BATTERY CHARGER - 10 AMP UL W/	
1146486	00	1	I	BATTERY CHARGER 10 AMP	View Diagram
1716844	03	1	I	CONNECTION GP - G	View Diagram
1847040	01	1	I	MTG GP - CHARGER	View Diagram
CA1073	01	1	I	OVERSIZE BATTERY	View Diagram
7L7872	08	1	I	24 VOLT BATTERY SET - DRY	View Diagram
1847031	00	1	I	CONTACTOR GP	View Diagram
CA1993	01	1	I	BREAKER GP-CIRCUIT-800 AMP-UL	Drawing... View Diagram
1690237	03	1	I	COVER GROUP-POWER TERMINAL	View Diagram
1694524	04	1	I	MOUNTING GROUP-BREAKER	View Diagram
1832489	01	1	I	BREAKER GP-CIRCUIT	View Diagram
1847038	00	1	I	WIRING GP. CIRCUIT BREAKER	View Diagram
1898892	01	1	I	CABLE GP - ELEC	View Diagram
CA1764	01	1	I	REMOVAL AR-1200 AMPS PTS	View Diagram
CA1774	01	1	I	COVER GP-CIRCUIT BREAKER- RIGHT	View Diagram
5N9698		1	I	NOTE- SINGLE BREAKER RIGHT	View Diagram
1057931	01	1	I	AUXILIARY SWITCH	View Diagram
5N9597		1	I	VOLTAGE INDICATOR 480V, 60HZ	View Diagram
0V1065		1	I	END USE: GENERAL EPG	View Diagram
9Y8156		1	I	STANDBY POWER APPLICATION	View Diagram
CA0866	02	1	I	LANGUAGE MARKINGS- ENGLISH	View Diagram
PP4127	02	1	I	749 BHP 515 GEN KW WOF 60 HZ S	View Diagram
2T9804	00	1	I	558.5 KW @ 1800 RPM (749 BHP)	View Diagram

Caterpillar Confidential: **Green**

Content Owner: Commercial Processes Division

Web Master(s): [PSG Web Based Systems Support](#)

Current Date: 10/16/2017 8:12:27 PM

© Caterpillar Inc. 2017 All Rights Reserved.

[Data Privacy Statement](#).