

ORDER INVOICE WITH ENGINEERING BREAKDOWN [5YF01309]

OCTOBER 19, 2019

For Help Desk Phone Numbers [Click here](#)

⚠ Caution Ordering Parts from TMI Order Invoice with Engineering Breakdown

Order Invoice with Engineering Breakdown information is provided by the orders system, once you click breakdown of a part, TMI pulls the information from the Engineering Data System (EDS).

EDS is not a manufacturing bill of material system but a engineering part in effect system. TMI uses the built date and calls EDS to pull the part in effect at that time.

Recently, TMI added an as manufactured tab. This tab provides the consist as reported from the engine factory. This data is limited but growing for new manufactured engines. To see an example enter "AT400559"

As-Manufactured tab is refreshed with correct data. The history records as well as the current data with wrong details are deleted. From 28th march 2019, TMI is maintaining only current data which possesses correct details.

To validate you are ordering a correct part, TMI encourages you to contact Morton Parts. 800-566-7782 or tech_support@cat.com

The below option will email full breakdown of the serial number

Excel PDF

FullBreakDown

Sales Model: 3208 DIT Invoice Number: GE 161862 Dealer: B130 S.O. Number: QK70900 Invoice Date: 1991-12-10

[Part Numbers](#)



[Help](#)

Part Numbers [Top](#)

64 results found, displaying 1 to 64

| Reference Number | Eng Chg | Quantity | ASM | LESS | Set Type | Description | BreakDown... | Reference Drawing | SIS Part Diagram |
|------------------|---------|----------|-----|------|----------|--------------------------------|------------------------------|----------------------------|------------------------------|
| PA3877 | 01 | 1 | I | | | 3208 200 EKW 60 HZ PGS-STBY | BreakDown... | | View Diagram |
| - 4P2649 | 00 | 1 | I | | | 3208 ENGINE AR. - BASIC | BreakDown... | | View Diagram |
| - 4P0422 | 02 | 1 | I | | | BASE GP - ENGINE & | BreakDown... | | View Diagram |
| - 1W6714 | 00 | 1 | I | | | LIFTING GP | BreakDown... | | View Diagram |
| - 3L0348 | | 1 | I | | | PACKAGE GS TEST - EMCP | BreakDown... | | View Diagram |
| - 4W0888 | 02 | 1 | I | | | SHUT-OFF GP-ELECTRICAL (24V) | BreakDown... | | View Diagram |
| - 5N7563 | | 1 | I | | | NOTE - CONTROL PANEL MTG (RH) | BreakDown... | | View Diagram |
| - 5N7577 | | 1 | I | | | CNTRL & PWR PANEL CHART 9Y1400 | BreakDown... | | View Diagram |
| - 5N7581 | | 1 | I | | | NOTE-RH GAGE PANEL & GOV CONT. | BreakDown... | | View Diagram |
| - 5N9079 | 02 | 1 | I | | | INSTALLATION ARRANGEMENT | BreakDown... | | View Diagram |
| - 5P2506 | 00 | 1 | I | | | LITERATURE GP | BreakDown... | Drawing... | View Diagram |
| - 7C5023 | 02 | 1 | I | | | MOUNTING GROUP - CONTACTOR | BreakDown... | | View Diagram |
| - 7C6513 | 06 | 1 | I | | | CONTROL GP | BreakDown... | | View Diagram |
| - 7C9128 | 00 | 1 | I | | | MOTOR GROUP - ELECTRIC START. | BreakDown... | | View Diagram |
| - 7E3125 | 01 | 1 | I | | | MTG GP | BreakDown... | | View Diagram |
| - 7N7613 | 01 | 1 | I | | | WATER PUMP DRIVE - RH | BreakDown... | | View Diagram |
| - 7W3354 | 01 | 1 | I | | | PICKUP GP. - MAGNETIC | BreakDown... | | View Diagram |
| - 7W5127 | 01 | 1 | I | | | BLOWER FAN | BreakDown... | | View Diagram |
| - 9Y0434 | 00 | 1 | I | | | SR4 GENERATOR AR. - POWER | BreakDown... | | View Diagram |

64 results found, displaying 1 to 64

| Reference Number | Eng Chg | Quantity | ASM | LESS  | Set Type | Description | BreakDown... | Reference Drawing | SIS Part Diagram  |
|------------------|---------|----------|-----|--|----------|--------------------------------|------------------------------|-------------------|--|
| - 9Y2201 | 00 | 1 | I | | | CLEANER GROUP - AIR | BreakDown... | | View Diagram |
| - 9Y2230 | 00 | 1 | I | | | SUPPORT GROUP - ENGINE | BreakDown... | | View Diagram |
| - 9Y2235 | 02 | 1 | I | | | LINES GROUP - DRAIN - COOLANT | BreakDown... | | View Diagram |
| - 9Y2236 | 04 | 1 | I | | | LINES GROUP - DRAIN - OIL | BreakDown... | | View Diagram |
| - 9Y2704 | 02 | 1 | I | | | CONNECTION GROUP | BreakDown... | | View Diagram |
| - 9Y2705 | 01 | 1 | I | | | PACKAGE WIRING - EMCP | BreakDown... | | View Diagram |
| - 9Y2932 | 00 | 1 | I | | | MOUNTING GROUP - CONTROL | BreakDown... | | View Diagram |
| - 9Y3662 | 00 | 1 | I | | | ADAPTER GROUP - AIR CLEANER | BreakDown... | | View Diagram |
| - 9Y3709 | 05 | 1 | I | | | AFTERCOOLER GROUP - AIR | BreakDown... | | View Diagram |
| - 9Y3714 | 06 | 1 | I | | | RADIATOR GROUP | BreakDown... | | View Diagram |
| - 9Y3720 | 00 | 1 | I | | | LINES GP-AIR (AFTERCOOLER) | BreakDown... | | View Diagram |
| - 9Y3722 | 04 | 1 | I | | | ENCLOSURE GP - GENERATOR | BreakDown... | | View Diagram |
| - 9Y3810 | 00 | 1 | I | | | WIRING GROUP | BreakDown... | | View Diagram |
| - 9Y5057 | 06 | 1 | I | | | ENCLOSURE GROUP - RADIATOR | BreakDown... | | View Diagram |
| 9Y4251 | 00 | 1 | I | | | BATTERY CHARGER 5 AMP | BreakDown... | | View Diagram |
| PA3815 | 00 | 1 | I | | | 1724 ELECTRONIC GOVERNOR | BreakDown... | | View Diagram |
| - 7C9184 | 01 | 1 | I | | | MTG GP - ACTUATOR | BreakDown... | | View Diagram |
| - 7E0597 | 00 | 1 | I | | | CONTROL AS - GOVERNOR | BreakDown... | | View Diagram |
| - 7E0598 | 00 | 1 | I | | | ACTUATOR GP | BreakDown... | | View Diagram |
| 9Y3036 | 00 | 1 | I | | | RADIATOR DUCT FLANGE | BreakDown... | | View Diagram |
| PA3166 | 00 | 1 | I | | | ENCLOSURE | BreakDown... | | View Diagram |
| - 9Y3698 | 05 | 1 | I | | | ENCLOSURE GP | BreakDown... | | View Diagram |
| - 9Y8473 | 01 | 1 | I | | | SHIELD GROUP - DRIP | BreakDown... | | View Diagram |
| PA3454 | 02 | 1 | I | | | MUFFLER | BreakDown... | | View Diagram |
| - 7E3501 | 00 | 1 | I | | | MOUNTING GP - MUFFLER | BreakDown... | | View Diagram |
| - 9Y5946 | 00 | 1 | I | | | MUFFLER GP - RESIDENTIAL | BreakDown... | | View Diagram |
| 9Y6366 | 01 | 1 | I | | | FLEXIBLE FUEL LINES | BreakDown... | | View Diagram |
| 7C5296 | 01 | 1 | I | | | REMOTE ANNUNCIATOR PANEL | BreakDown... | | View Diagram |
| PL4726 | 04 | 1 | I | | | JACKET WATER HEATER | BreakDown... | | View Diagram |
| - 7E6250 | 02 | 1 | I | | | HEATER GP-JACKET WATER | BreakDown... | | View Diagram |
| - 9Y5937 | 01 | 1 | I | | | MOUNTING GP - JW HEATER | BreakDown... | | View Diagram |
| 3N7056 | 00 | 1 | I | | | BATTERY RACK | BreakDown... | | View Diagram |
| 0P9814 | | 1 | I | | | M_____3 EMCP PANEL | BreakDown... | | View Diagram |
| 9Y3839 | 04 | 1 | I | | | SERIES BOOST KIT | BreakDown... | | View Diagram |
| PA2844 | 03 | 1 | I | | | CIRCUIT BKR W/ST 300-400 A | BreakDown... | | View Diagram |
| - 3L0357 | | 1 | I | | | INSTRUCTIONS - BREAKER ADJUST | BreakDown... | | View Diagram |
| - 4W8211 | 02 | 1 | I | | | INSULATORS | BreakDown... | | View Diagram |
| - 7W0921 | 02 | 1 | I | | | WIRING GROUP WITH SHUNT TRIP | BreakDown... | | View Diagram |
| - 9Y0959 | 00 | 1 | I | | | BREAKER AS-CIRCUIT-300-400 AMP | BreakDown... | | View Diagram |
| - 9Y0973 | 02 | 1 | I | | | CIRCUIT BREAKER MOUNTING | BreakDown... | | View Diagram |
| - 9Y2923 | 02 | 1 | I | | | PLATE - COVER | BreakDown... | | View Diagram |
| PP1052 | 01 | 1 | I | | | 299BHP 206GEN KWWOF 60HZ STDBY | BreakDown... | | View Diagram |
| - 0T9361 | 00 | 1 | I | | | 223 KW @ 1800 RPM (299 BHP) | BreakDown... | | View Diagram |
| - 4N6119 | 01 | 1 | I | | | SPRING-GOVERNOR | BreakDown... | | View Diagram |
| - 5N7545 | | 1 | I | | | NOTE-REMOVE STD GOV SPRING. | BreakDown... | | View Diagram |

Caterpillar Confidential: **Green**

Content Owner: Commercial Processes Division

Web Master(s): [PSG Web Based Systems Support](#)

Current Date: 10/19/2019, 9:07:50 AM

© Caterpillar Inc. 2019 All Rights Reserved.

[Data Privacy Statement.](#)