

ORDER INVOICE WITH ENGINEERING BREAKDOWN [4FD01980]

MARCH 02, 2017

For Help Desk Phone Numbers [Click here](#)



Caution Ordering Parts from TMI Order Invoice with Engineering Breakdown

Order Invoice with Engineering Breakdown information is provided by the orders system, once you click breakdown of a part, TMI pulls the information from the Engineering Data System (EDS).

EDS is not a manufacturing bill of material system but a engineering part in effect system. TMI uses the built date and calls EDS to pull the part in effect at that time.

Recently, TMI added an as manufactured tab. This tab provides the consist as reported from the engine factory. This data is limited but growing for new manufactured engines. To see an example enter "WRH00104"

To validate you are ordering a correct part, TMI encourages you to contact Morton Parts. 800-566-7782 or tech_support@cat.com

The below option will email full breakdown of the serial number

Excel PDF

FullBreakDown

Sales Model: 3406
SITA

Invoice
Number:GEDR5101086

Dealer:
D100

S.O. Number:
CJW0700

Invoice Date: 1999-
06-04

[Part Numbers](#)

[Help](#)

Part Numbers [Top](#)

66 results found, displaying 1 to 66

Reference Number	Eng Chg	Quantity	ASM	LESS	Set Type	Description	Reference Drawing	SIS Part Diagram
LA2628	01	1	I			G3406 TA 60 HZ PGS - STANDBY	Drawing...	View Diagram
1525067	00	1	I			3406 GAS INDUSTRIAL ENG-BASIC		View Diagram
2W7846	00	1	I			FLEXIBLE FITTING	Drawing...	View Diagram
3L0432		1	I			TEST - PKG GEN SET (EMCP II)		View Diagram
4N0691	20	1	I			MANIFOLD GP-WATER COOLED EXH.		View Diagram
4N1062	10	1	I			ELECTRIC STARTING MOTOR LH 24V	Drawing...	View Diagram
4P1738	06	1	I			IGNITION GP		View Diagram
4P5534	05	1	I			CONNECTION GP -E		View Diagram
4P8994	01	1	I			LOW WATER TEMPERATURE SWITCH		View Diagram
4P9313	01	1	I			LINES GP - WATER		View Diagram
5N7562	00	1	I			NOTE-CONTROL PANEL MTG (REAR)		View Diagram
	00	1	I			LITERATURE GP - ENGLISH	Drawing...	View Diagram

5P2506	-						
6I0280	-	04	1	I	BYPASS GP - EXHAUST		View Diagram
6I4456	-	01	1	I	MOUNTING GP-JACKET WATER HEATR		View Diagram
7C1052	-	03	1	I	DRIVE GP - ACCESSORY		View Diagram
7C6133	-	03	1	I	LINES GP - TURBO OIL		View Diagram
7C9706	-	06	1	I	AFTERCOOLER GP		View Diagram
7C9716	-	06	1	I	CLEANER GP - AIR		View Diagram
7C9731	-	03	1	I	MOUNTING GP - AIR CLEANER		View Diagram
7C9733	-	05	1	I	COVER GP - STORAGE		View Diagram
7E6247	-	02	1	I	JACKET WATER HEATER		View Diagram
7X2425	-	01	1	I	OIL - BULK - 1 LITER		View Diagram
9Y3052	-	03	1	I	REGULATOR GP		View Diagram
9Y3363	-	01	1	I	LINES GP - AIR		View Diagram
9Y9809	-	02	1	I	TURBOCHARGER GP		View Diagram
9Y9812	-	03	1	I	CARBURETOR GP-LOW PR GAS		View Diagram
9Y9840	-	01	1	I	CONVERSION GP - GOVERNOR		View Diagram
1030026	-	01	1	I	PAINT GP AND TRANSFER	Drawing...	View Diagram
1038974	-	04	1	I	CONNECTION GP -G		View Diagram
1044704	-	03	1	I	MTG GP - CONTROL PNL (EMCP II)		View Diagram
1117200	-	00	1	I	LINES GP - DRAIN (OIL)		View Diagram
1196031	-	06	1	I	PANEL AS-CONTROL		View Diagram
1210742	-	00	1	I	WIRING GP		View Diagram
1213890	-	01	1	I	CONTROL GP-B		View Diagram
1291645	-	00	1	I	HEAVY DUTY SKIDABLE BASE		View Diagram
1413204	-	00	1	I	ACTUATOR GP		View Diagram
1413208	-	00	1	I	CONTROL AS - GOVERNOR		View Diagram
1461860	-	00	1	I	SWITCH GROUP		View Diagram
1466771	-	01	1	I	PUMP GROUP-AUX		View Diagram
1466784	-	00	1	I	LINES GROUP-WATER		View Diagram
1524810	-	01	1	I	VALVE GROUP-SOL		View Diagram
LA2148	-	00	1	I	GENERATOR REMOVAL 447 FRAME		View Diagram
LA2150	-	00	1	I	GENERATOR 447 FRAME PM		View Diagram
1093319	-	02	1	I	INSTALLATION ARRANGEMENT		View Diagram
1213193	-	01	1	I	GENERATOR AR-POWER SR4B		View Diagram
1214712	-	01	1	I	PANEL LIGHTS/AUXILIARY RELAY		View Diagram
1214713	-	00	1	I	ENGLISH DISPLAY UNITS		View Diagram
1214716	-	01	1	I	ALARM MODULE - NFPA 99	Drawing...	View Diagram
7N8840	-	02	1	I	FAN DRIVE 0.800 RATIO	Drawing...	View Diagram

4N3093	08	1	I	BLOWER FAN	Drawing...	View Diagram
1684590	01	1	I	ADAPTER GROUP - FAN		View Diagram
PA5219	00	1	I	CIRCUIT BKR W/ST 400 A		View Diagram
4P5719	-	00	1	CIRCUIT BREAKER COVER		View Diagram
4P7146	-	02	1	MOUNTING GP-BREAKER		View Diagram
6I3340	-	00	1	BAR AS-NEUTRAL-800 AMP		View Diagram
1044387	-	00	1	BREAKER GP - CIRCUIT		View Diagram
1057185	-	00	1	WIRING GP		View Diagram
1061771	-	00	1	FASTENER GP		View Diagram
1073056	-	00	1	BOX GP - EXTENSION		View Diagram
5N9597		1	I	VOLTAGE INDICATOR 480V, 60HZ		View Diagram
0P8707		1	I	NO. _____ QUOTE		View Diagram
0P8910		1	I	POST SALE SPAR		View Diagram
0P9397		1	I	CIRCUIT BREAKER DISCLAIMER		View Diagram
5Z3333	00	1	I	***SPECIAL SETTING REQUEST****		View Diagram
LL9181	00	1	I	373 BHP 235 GEN KW WOF 60 HZ		View Diagram
0K0829	-	00	1	278 KW @ 1800 RPM (373 BHP)		View Diagram

Caterpillar Confidential: **Green**

Content Owner: Commercial Processes Division

Web Master(s): [PSG Web Based Systems Support](#)

Current Date: 3/2/2017 6:27:04 AM

© Caterpillar Inc. 2017 All Rights Reserved.

[Data Privacy Statement](#).